Ef certifix INSULATION FIXINGS AND DISCS FOR CONCRETE



Fast and easy to use, A2 or Zinc-plated fire retardant support anchor.

PRODUCT DESCRIPTION

The A2 or Zinc-Plated fire rated insulation support anchor. Simply hammer the anchor into the prepositioned insulation, and the anchor will expand into the substrate, securing the load. The hammer installation allows fast setting and reducing the amount of work.

PRODUCT FEATURES

- Approved for multiple fastenings of insulation panels
- High load-bearing capacity in cracked and non-cracked concrete
- Small drill holes
- Quick and safe installation

Ef certifix

MATERIAL

- Zinc-Plated Steel -ISA-Z
- A2 Stainless Steel -ISA-S
- Zinc-Plated Steel -ISA-Z D
- A2 Stainless Steel –ISA-S D
- ISA-S/ISA-Z + Cap –ISA-SP, ISA-ZP

BASE MATERIAL

- Approved for C20/25 - C50/60 concrete
- Approval in both cracked and non-cracked concrete

TECHNICAL CHARACTERISTICS WITHOUT FIRE EXPOSURE


		Cer	tifix Insulation Anchor ISA
DRILL BIT DIAMETER	d ₀	[mm]	8
DEPTH OF DRILL HOLE	h1 ≥	[mm]	45
EFFECTIVE ANCHORAGE DEPTH	h _{ef} ≥	[mm]	40
MINIMUM THICKNESS OF MEMBER	hmin	[mm]	80
EDGE DISTANCE	С	[mm]	60
SPACING	S	[mm]	120
PERMISSIBLE LOAD IN CRACKED AND NON-CRACKED CONCRETE C20/25 -C50/60 ^{1/2²}	Nzul	[kN]	0.074

The partial safety factor for material resistance from the approval yM=1.5 as well a partial safety factor for load actions yF=1.4 were considered for determining the load.

TECHNICAL CHARACTERISTICS UNDER FIRE EXPOSURE					
Fire Resistance Class		Certif	ix Insulation Anchor ISA		
R30	Permissible Load Ffi,per,30 1)	[kN]	0.09		
R60	Permissible Load Ffi,per,60 1)	[kN]	0.09		
R90	Permissible Load Ffi,per,90 1)	[kN]	0.09		
R120	Permissible Load Ffi,per,120 1)	[kN]	0.09		
R180	Permissible Load Ffi,per,180 1)	[kN]	0.06		
R30-R120	Spacing sfi Edge Distance cfi	[mm]	120		

The partial safety factor for material resistance from the approval y_M = 1.5 as well a partial safety factor for load actions y_F = 1.4 were considered for determining the load.

INSTALLATION INSTRUCTIONS



1) Set drill hole

- 2) Clean out drill hole from the base
- 3) Knock insulation fastener through the insulation panel with a hammer
- 4) Anchor disc must fully contact the insulation panel

Minimum 4 anchors per square meter for insulation panel. The dimension between axes and edge distance is valid without fire exposure. Assumed that an application is forced with fire exposure.



