

# **CERTIFIX INSULATION FIXINGS**

And Discs for Concrete



#### PRODUCT DESCRIPTION

The A2 or Zinc-Plated fire rated insulation support anchor. Simply hammer the anchor into the prepositioned insulation, and the anchor will expand into the substrate, securing the load. The hammer installation allows fast setting and reducing the amount of work.

# PRODUCT FEATURES

- Approved for multiple fastenings of insulation panels
- High load-bearing capacity in cracked and non-cracked concrete
- Small drill holes
- Can be coated to any colour within around 5 10 working days
- Quick and safe installation





#### TECHNICAL CHARACTERISTCS WITHOUT FIRE EXPOSURE

			CERTIFIX INSULATION ANCHOR ISA
Drill Bit Diameter	$d_0$	[mm]	8
Depth of Drill Hole	h1 ≥	[mm]	45
Effective Anchorage Depth	h <sub>ef</sub> ≥	[mm]	40
Minimum Thickness of Member	hmin	[mm]	80
Edge Distance	С	[mm]	60
Spacing	S	[mm]	120
Permissible load in cracked and non-cracked concrete C20/25 – C50/60 <sup>1/2</sup>	Nzul	[kN]	0.074

The partial safety factor for material resistance from the approval yM = 1.0 as well a partial safety factor for load actions yF = 1.0 were considered for determining the load.

#### MATERIAL

- Zinc-Plated Steel: ISA-ZA2 Stainless Steel: ISA-S
- Zinc-Plated Steel: ISA-Z D
- A2 Stainless Steel: ISA-S D, ISA-S/ISA-Z + Cap ISA-SP, ISA-ZP

#### BASE MATERIAL

- Approved for C20/25 C50/60 concrete
- Approval in both cracked and non-cracked concrete




## TECHNICAL CHARACTERISTCS UNDER FIRE EXPOSURE

			CERTIFIX INSULATION ANCHOR ISA
Fire Resistance Class			
R 30	Permissible Load Ffi, per,30 1)	[kN]	0.09
R 60	Permissible Load Ffi, per,60 1)	[kN]	0.09
R 90	Permissible Load Ffi, per,90 1)	[kN]	0.09
R 120	Permissible Load Ffi, per,120 1)	[kN]	0.09
R 180	Permissible Load Ffi, per,180 1)	[kN]	0.09
R 30 – R 120	Spacing s <sub>fi</sub>	[mm]	120
	Edge Distance $c_{_{\mathrm{fi}}}$		

The partial safety factor for material resistance from the approval yM = 1.0 as well a partial safety factor for load actions yF = 1.0 were considered for determining the load.

### INSTALLATION INSTRUCTIONS



- 1. Set drill hole
- 2. Clean out drill hole from the base
- 3. Knock insulation fastener through the insulation panel with a hammer
- 4. Anchor disc must fully contact the insulation panel

Minimum 4 anchors per square meter for insulation panel. The dimension between axes and edge distance is valid without fire exposure. Assumed that an application is forced with fire exposure



